

# Lightning & USB-C Controls

• **Single Press:** Play / Pause / Answer / Terminate Call

▬ **Long Press:** Voice Assistant

•• **Double Press:** Next Track

••• **Triple Press:** Previous Track

• ▬ **Single Press Then Hold:** Fast Forward

•• ▬ **Double Press Then Hold:** Rewind



**Single Press:** • Incremental Volume Increase

**Long Press:** ▬ Continuous Volume Increase

**Single Press:** • Incremental volume decrease

**Long Press:** ▬ Continuous Volume Decrease